HD-V2 Assembly

Tools Needed



#3 Phillips Screwdriver

7/16" Wrench

To assemble your HD-V2 watch the following instructional video:

ASSEMBLY VIDEO



ammoupusa.com/hd-v2-assembly

SCAN CODE

Flip over for use and care instructions

Have Questions? Give us a call or email us at: 904-641-3934 or info@ammoupusa.com

HOW TO USE

HOW TO USE VIDEO
ammoupusa.com/HD-V2.com
SCAN CODE

DO NOT REVERSE
on wheel assembly (B)

Wash hands after handling brass

Use caution when lifting basket and rolling the HD V2

Inspect and tighten nuts and bolts occasionally



INDOOR

• **Picking Up**: When using the Ammo-Up indoors, evenly distribute the weight of the machine between the wheel assembly [B] and the small front wheels [C]. Do not push brass into a pile before picking up. It picks up best when the brass is in a single layer. If your wheels stop rolling during pick-up (normally due to a large amount of brass), reverse a few inches and firmly push the machine forward to eject the clump of brass from the ejector fingers [D].

• **Reversing**: When backing up indoors, pivot the HD V2 up onto the small front wheels [C] and roll back, keeping all the weight off the black wheel assembly [B].

• **Turning**: When turning on the concrete lift the wheel assembly up [B] and turn on the small front wheels [C]. This will prolong the life of your wheel assembly [B].

• **To Empty Your Basket**: Lift the basket [A] using the handle on top of the basket. Dump the contents of the basket into the desired container. When empty, slide the basket back into the grooves on the machine.

OUTDOOR

• **Picking Up**: When picking up on grass or dirt, we recommend walking with the handle [E] pressed down. This will elevate the basket [A], placing all the weight on the wheel assembly [B]. This allows the black tines to dig deeper into the ground.

• **Reversing**: Try to avoid reversing outside. We recommend always walking forward. This will prevent the ejector fingers [D] from lifting.

• **Turning**: When turning on grass or dirt, push the handle [E] down to elevate the small front wheels [C] off the ground so you can turn on the wheel assembly [B]. Try to avoid using small front wheels [C] in the grass and dirt.

• **To Empty Your Basket**: Lift the basket [A] using the handle on top of the basket. Dump the contents of the basket into the desired container. When empty, slide the basket back into the grooves on the machine.

• **Maintain Clean Grounds**: The cleaner your ground is, the more efficient the HD V2 will operate. If possible, mow and remove any debris in the area prior to using your Ammo-Up.