10601 Theresa Drive, Jacksonville, Florida 32246
1-904-641-3934 • www.AmmoUpUSA.com

A8006

36" Pull Behind Brass Collector



IMPORTANT
Read before use

- **Maintain Clean Grounds:** The cleaner your ground is, the better the unit will operate. If you can, **mow it and blow it prior to cleanup.**
- **Move Forward Only:** Try to go forward only, at all times. If you go more than a half rotation backwards, ejector fingers [B] can become disengaged. If they do become disengaged, push them back down in between the collector wheels [A].
- **To Empty Your Basket:** Lift basket [G] with slits on the side. Dump basket of contents into any desired location. When empty, replace basket between grooves on machine.
- **Loose Wheels (Shells aren't being caught in wheels):** If you have loose wheels [A], use a 7/16" deep well socket wrench to tighten wheel drum located on the sides of the machine [J].
- **Loose Fingers:** If you have loose fingers, apply spacers to the finger shaft [D].
- **Other Tips and Troubleshooting:** We offer many videos on YouTube that can assist in assembling and operating your Ammo-Up. Visit *www.youtube.com/ammoupusa* to view these helpful videos.
- **Service and Parts:** If you have any parts or service issues, we are always happy to help, please call us at 904-641-3934 or 800-940-2688 or email *info@AmmoUpUSA.com*.

Made in U.S.A.

Parts List

F0033 Small Brass Wheel-Blue [A]		
F0070 Brass Finger-Black-SM [B]		
F0071 Triangle Side Bracket [C]		
S0111 Snap-on Spacer Pack of 10 [D]		
S0213 Graphite Wheel Shaft 40 1/8" [E]		
P2000 Pipe, 20"		
S0217 Rubber Sweeper [N]		
X3009 76mm Wheel [K]		

S0207 36" Aluminum Push Handle [F]		
S0119 Hook Basket, Small w/ liner [G]		
S0210 Threaded Rod, 41 3/8" [H]		
S0216 Threaded Rod, 44 13/16" [L]		
X0081 Lock Nut, 1/4" x 20" [J]		
S0126 Washers, Pack of 5 Big, 2 Small [I]		
X3016 Metal Washer, 1"		
X3022 Metal Washer, 1 1/4"